

TV OPERATION



1. Turn on TV and DirectTV

5. Turn off

2. Press "Guide" to find shows

3. Use arrows to scroll, then press "Select" to pick highlighted shows

4. Volume and Channel controls